


ADT-TP3540DJ

Double-Station Dispenser System

User Manual



ADTECH 众为兴

ADTECH (SHENZHEN) TECHNOLOGY CO., LTD.

Add: 5th floor, 27-29th Building, Tianxia IC Industrial Park,
Yiyuan Road, Nanshan District, Shenzhen, China P.C:518052

TEL: 0755-26722719

FAX: 0755-26722718

Email: tech@adtechcn.com

<http://www.adtechcn.com>

Copyright

Adtech (Shenzhen) Technology Co., Ltd. (Adtech hereafter) is in possession of the copyright of this manual. Without the permission of Adtech, the imitation, copy, transcription and translation by any organization or individual are prohibited. This manual doesn't contain any assurance, stance or implication in any form. Adtech and the employees are not responsible for any direct or indirect data disclosure, profits loss or cause termination caused by this manual or any information about mentioned products in this manual. In addition, the products and data in this manual are subject to changes without prior notice.

All rights reserved.

Adtech (Shenzhen) Technology Co., Ltd.

Version History

Item No.	First uploaded on	Version No.	Pages	Compiled by	Typeset by
BZ001B080A	2012-9-22	A0201	48	Shu Guo	
Revision					
Date	Version/Page	Result	Confirmed by		

Precautions

※ Transportation and storage

- ☞ The packaging boxes shouldn't be stacked more than six layers
- ☞ Do not climb onto, stand on or put heavy objects on the packaging box
- ☞ Do not drag or convey the product with a cable connected to the product
- ☞ Do not impact or scratch the panel and display
- ☞ Keep the packaging box away from moisture, insulation and rain

※ Unpacking and checking

- ☞ Unpack and check whether the product is the one you ordered
- ☞ Check whether the product is damaged during transporting
- ☞ Check whether the parts are complete and intact according to the packing list
- ☞ If the model doesn't match, any accessories are missing or damaged, please contact us immediately

※ Wire connection

- ☞ The personnel for wire connection and checking should be qualified
- ☞ The product must be grounded reliably (resistance $< 4\Omega$) and do not use neutral wire to replace the earth wire
- ☞ The wires must be connected properly and firmly to avoid failures and accidents
- ☞ The surge absorption diode must be connected to the product properly, or else it will damage the product
- ☞ Please cut off the power supply before inserting/removing the plug or opening the enclosure

※ Checking and repairing

- ☞ Please cut off the power supply before repairing or replacing the components
- ☞ Check the failure if short circuit or overload occurs, and restart after eliminating all failures
- ☞ Do not connect/cut off the power supply frequently; wait for at least one minute before restarting

※ Others

- ☞ Do not open the enclosure without permission
- ☞ Please cut off the power supply if it won't be used for a long time
- ☞ Prevent dust and iron powder from entering the controller
- ☞ If non-solid state relay is used for output, please connect freewheeling diode to relay coil in parallel. Check whether the connected power supply is qualified to avoid burning out the controller
- ☞ The lifetime of the controller depends on the environment temperature. If the temperature of processing field is too high, please install cooling fan. The allowable temperature range of the controller is 0°C - 60°C
- ☞ Avoid using in the environment with high temperature, moisture, dust or corrosive gas
- ☞ Install rubber cushion if the vibration is severe

※ Maintenance

Under normal condition (environment: daily average 30°C , load rate 80%, running rate 12 hours every day), please perform daily and periodic checking according to the items below.

Daily checking	Daily	● Confirm environment temperature, humidity and dust ● Whether there is abnormal vibration or sound
Periodic checking	1 year	● Whether the fixed parts are loose ● Whether the terminal block is damaged

Contents

1 System Overview	5
1.1 Hardware Features	5
1.2 Software Features	6
1.3 Fittings List	6
1.4 Structural Dimensions	7
2 Operating Instructions	8
2.1 Step 1: Main Interface	8
2.2 Step 2: Viewing software version	9
2.3 Step 3: Updating the programs	10
2.4 Step 4: Hardware connecting and I/O test	11
2.5 Step 5: Factory parameter setting	16
2.6 Step 6: Setting system parameters	23
2.7 Step 7: Setting user parameters	30
2.8 Step 8: Setting processing parameters	31
2.9 Step 9: Choosing/Creating processing file	32
2.10 Step 10: Setting file parameters	35
2.11 Step 11: Editing files	38
2.12 Step 12: Processing operation	39
3 Details of File Edition	43
3.1 File editing interface	43
3.2 Selecting type of processing instruction	46
3.3 Modifying data of processing point	49
3.3.1 Manual input	49
3.3.2 Teach	51
3.4 Constraint condition for the type of processing point	53
3.5 Skills for continuous teaching	55
4 Advanced Applications	55
4.1 Advanced editing functions	55
4.1.1 Batch edit	56
4.1.2 Array copy	60
4.1.3 Z-axis depth	61
4.1.4 Needle height	61
4.1.5 Batch delete	61
4.1.6 Automatic corner	61
4.1.7 Extend program	65
4.1.8 Graphics library	65
4.1.9 Find type	77
4.1.10 Adjust area	77
4.1.11 Multiple arrays	78
4.2 PLT graph importing function	79
4.2.1 Use CorelDRAW 12 to generate PLT files	79
4.2.2 Use AutoCAD2004 to generate PLT files	81
4.2.3 Changing sequence of PLT file track with CorelDRAW12	84
4.2.4 Importing dxf files with CorelDRAW12	88
4.3 G code importing function	89
4.4 TCF file conversion function	89
4.5 USB connection and USB disk usage	89

1 System Overview

TP3540 4-axis double-station dispenser control system allows setting the single station and double station. The system completes operations such as human-machine interface, motion control and IO port, achieving 3-dimension, high precision and dedicated motion control system. This system supports 4 motion axes and 8 dispensing output controls, providing users with abundant instruction set, which includes motion instructions such as straight line, circular arc, single point, and oval. In addition, instructions like port output, wait for input, pause and delay, glue gun selecting, and motor reset are provided, as well as many other advanced editorial functions, including batch modification, array copy, graphics shift, graph zoom in and zoom out, auto round corner, and frequently-used graphics library. Besides setting coordinates manually and in teaching, the system also supports importing PC graphics, which can be converted to PLT file, TCF file or G-code files, and further converted to processing files by the controller for processing. Each processing file can save 100 thousand processing points with 128MB memory. This system also supports USB flash drive reading and writing, and allows reading and writing the processing files on USB disk directly.

1.1 Hardware Features

- Display: TFT5.6" 24-bit true color touch screen, 640*480 pixels
- Slim design, compact
- Motor axis No.: 4 axes (XYZU)
- Pulse frequency: 2MHz; if the pulse of motor per turn is 25600, the maximum speed can then reach 5000 turn/min
- Numbers of IO interface: 16-line dedicated input (XYZU origin, positive & negative limit, start-up 1, start-up 2, stop, reset button), 16-line general input, 16-line dedicated output; when the positive & negative limit in dedicated input are not used, the ports can be used as general input; when U axis isn't used, the origin port can be used as general input; in single station, start-up 2 can be used as general input.
- IO input type: OC isolation input
- IO output type: short circuit protection; maximum output current: 1A
- Communication: RS232, USB flash drive, USB communication, Ethernet
- Memory space: 128MB; a processing file can occupy a space of as large as 3MB (100 thousand processing points)
- Operating voltage: 24V DC
- Operating temperature: 45°C
- Storage temperature: -40°C —55°C
- Operating humidity: 40%—80%
- Storage humidity: 0%—95%


1.2 Software Features

- Support the 3-axis linear interpolation, 3-axis arc interpolation and elliptical arc interpolation.
- Speed look-ahead algorithm is adopted to smooth the turning speed automatically.
- PC picture import is supported. PLT files, TCF files and G code files can be imported.
- Feature the delay opening glue-gun and advance closing glue-gun for track, resolving the glue piling at the starting point and the end-point.
- Contain abundant motion instructions and auxiliary instruction sets.
- With user-friendly file instruction and edition functions, offering many advanced editorial functions such as batch modification, array copy, picture translation, picture zoom, and auto fillet; common graph library is provided for users for their convenient use.
- Graphical display function enables to show the shape of graphics in the processing files clearly.
- Processing track is shown in real time dynamically.
- Cycle processing, single processing, auto processing, and single step processing are supported.
- The color of background and keys can be customized.

1.3 Fittings List

Fitting Name	Model	Qty.	Profile
4-axis motion controller	TP3540	1 set	Interface operation and motion control
PCBA	TP3540 F2 VER:B	1 piece	Port terminal board
Data transmission line	L0130262GG1	1 piece	Used for the connect the controller and port terminal board
USB download cable	L1319200001	1 piece	USB cable to connect the controller and PC

1.4 Structural Dimensions



2 Operating Instructions

2.1 Step 1: Main Interface

When the machine is connected to the power supply and powered on, it enters the main interface as below:



工位一

Station 1

工位二

Station 2



Select file

Parameter Settings

File Edit

Align Tool

Process

加工时间

Processing time

当前指令:

Current instruction:

当前状态:

Current state:

单步运行
禁止开胶

Single step running

Disable open glue

系统设置 文件管理

System Settings / File Manager

硬件测试 版本信息

Hardware Test / Version Info

复位 暂停 停止

Reset / Pause / Stop

The single station and double station of the system can be set; refer to factory parameter settings for details (2.5 step 5: set factory parameter)


Boot screen and the main interface background images:


You may use the "Paint" program provided by Windows to produce a 640 * 480 pixel true color images in ".bmp" format, the boot screen named "logo.bmp", the main interface background image named "back.bmp", put them to the TP3540's "\\ADT\\" directory.

For the key functions in the main interface, refer to "Step 12: Processing".

2.2 Step 2: Viewing software version

In the main interface, press "Version Info" to view the software version:





Version Info

Item No.: BZ001B080A

Main program version: 2.1.76

Terminal motion library version: 0.1.75

FPGA program version: 3513

Program generation date: August 13, 2012

Program generation time: 14:30:19

Written by: Tang Gongyi

Exit



Reset / Pause / Stop

Generally, just note the main program version.

2.3 Step 3: Updating the programs

The program should be updated if the program version of the controller isn't latest.

- Copy program to controller (3 ways)
 - 1) Via serial port (the first time of updating must use this method.)

Connect the D-shape USB interface of TP3540 to the USB port of PC, restart the device, press and hold the human-machine interface when "*****" appears in the upper left of the interface to enter "System start interface", select "1-USB disk" as prompted, then, TP3540 will be connected to PC as a USB disk, and you can copy TP3540 client (file name: adtrom.bin) to "\ADT\" directory of the controller through PC.
 - 2) Connect TP3540 to the USB interface of PC, turn on the power, enter "File Manager" interface, press "USB connection", TP3540 will be connected to PC as a USB disk, and then you can copy TP3540 client (file name: adtrom.bin) to "\ADT\" directory of the controller through PC.
 - 3) Connect the USB disk to TP3540, enter "File Manager" -> "File Operation" interface, and then copy the client (file name: adtrom.bin) to "\ADT\" directory of the controller.
- Update the client.

Copy the program to TP3540, select "2-Update" as prompted. After update, turn off the power and restart the device or press "3-Restart" to run the latest program.

2.4 Step 4: Hardware connecting and I/O test

In the main interface, press “Hardware Test” to enter the interface of hardware testing:






Hardware Test



In above figure, the four lines from “X origin” to “DI31” are 32 input ports. You can press “Output control” to switch to output port key interface, corresponding to opening and closing of the 16 output ports. DI is input signal, and DO is output signal. Please follow the wiring drawings below to test whether the positive inversion of motor is normal, and whether input signal and output signal are one-to-one corresponding.

Wiring diagram:





Connect to 24VDC
Common terminal

Manual X positive
Manual X negative
Manual Y positive
Manual Y negative
Manual Z positive
Manual Z negative

Teach

*在参数·厂商参数设置-->使用外部手动按键·为·是·时，手动按键（端口DI16到DI23）功能有效；为·否·时，端口为通用端口。

*接线板上只有引脚定义，引脚定义不等于引脚号。接线板上的引脚定义跟接线图中的引脚定义相对应。
例如INPUT J4 输入端口中
接线板上的0、1...15、COM2
对应于接线图中的DI00、DI01...DI15、COM2。INPUT J2
输入端口对应关系同理


* If “Factory parameter settings → Use external manual key” is set to “Yes”, manual key (port DI16 to DI23) function is valid; if it is “No”, the port is used as general port.

* The terminal board only has pin definition, which isn't pin number. The pin definition on the terminal board corresponds to the pin definition in the wiring diagram.

For example, in INPUT J4, 0, 1...15, COM2 on the terminal board corresponds to DI00, DI01...DI15, COM2 on the wiring diagram. Input port correspondence of INPUT J2 is similar.

客户	通用客户	项目号	BZ001B080A	
项目名称	TP3540DJ点胶机系统			
图名	TP3540点胶机输入接线图	页码	1/2	
绘图	舒果	日期	2012/08/29	版本
		A3		
深圳众为兴技术股份有限公司				

Client	Universal		Item No.	BZ001B080A	
Item name	TP3540DJ Dispenser System				
Drawing name	TP3540DJ Dispenser Input Wiring Diagram			Page	1/2
Drawn by	Shu Guo	Date	2012/08/29	Version	A3
ADTECH (SHENZHEN) TECHNOLOGY CO., LTD.					



胶枪开关1		Glue gun switch 1
胶枪开关2		Glue gun switch 2
胶枪开关3		Glue gun switch 3
胶枪开关4		Glue gun switch 4
胶枪开关5		Glue gun switch 5
胶枪开关6		Glue gun switch 6
胶枪开关7		Glue gun switch 7
胶枪开关8		Glue gun switch 8
换枪开关1		Glue gun change switch 1
换枪开关2		Glue gun change switch 2
换枪开关3		Glue gun change switch 3
换枪开关4		Glue gun change switch 4
换枪开关5		Glue gun change switch 5
换枪开关6		Glue gun change switch 6
换枪开关7		Glue gun change switch 7
换枪开关8		Glue gun change switch 8
外接24V电源地		Connect to 24V power grounding
外接直流24V		Connect 24VDC

VCC_5V为X、Y、Z、U轴的共阳极接法公共端

VCC_5V is the common terminal of X, Y, Z and U axes in common anode connection method

U轴驱动器	Z轴驱动器	Y轴驱动器	X轴驱动器
U-axis drive	Z-axis drive	Y-axis drive	X-axis drive

*在参数‘厂商参数设置-->输出端口配置’中可配置使用的胶枪开关、换枪控制端口；未配置的输出端口可做通用输出端口。

*OUTPUT J3 输出端口中接线板上的0、1...15、E0V、E24V对应于接线图中的DO00、DO01...DO15、E0V、E24V。电机接线端口J1中对应XYZU四轴的接线，各轴中D-负方向，D+正方向，P-负脉冲，P+正脉冲

* The control ports glue gun switch and glue gun change can be configured in “Factory parameter settings → Output port configuration”; the output ports that aren’t configured can be used as general output ports.


* In OUTPUT J3, 0, 1...15, E0V, E24V on the terminal board corresponds to DO00, DO01...DO15, E0V, and E24V on the wiring diagram. Motor wiring port J1 corresponds to the wire of XYZU axes, of which D- is negative direction, D+ is positive direction, P- is negative pulse and P+ is positive pulse

客户	通用客户	项目号	BZ001B080A
项目名称	TP3540DJ点胶机系统		
图名	TP3540点胶机输出接线图	页码	2/2
绘图	舒果	日期	2012/08/29
		版本	A3
深圳众为兴技术股份有限公司			

Client	Universal		Item No.	BZ001B080A	
Item name	TP3540DJ Dispenser System				
Drawing name	TP3540DJ Dispenser Input Wiring Diagram			Page	2/2
Drawn by	Shu Guo	Date	2012/08/29	Version	A3
ADTECH (SHENZHEN) TECHNOLOGY CO., LTD.					

2.5 Step 5: Factory parameter setting

In the main interface, press “System Settings” -> “Factory parameter setting” and enter the interface of factory parameter setting:



系统设置	System Settings
厂商参数设置	Factory parameters
系统参数设置	System parameters
用户参数设置	User parameters
加工参数设置	Processing parameters
保留功能	Reserved function

页: 01 / 01	确定	取消
------------	----	----

Page 01/01 OK Cancel

厂商参数设置

厂商参数设置密码:

是否启用掉电记忆功能:

电机特性设置:

启动按钮加暂停功能:

轨迹拆分精度(毫米):

使用外部手动按键:

拐角减速系数:

输出端口配置:

停止按钮抬起复位:

输入端口配置:

下页 页: 01 / 02 **确定** **取消**

厂商参数设置	Factory parameters settings	是否启用掉电记忆功能: 否	Enable power failure memory: No
厂商参数设置密码	Password	启动按钮加暂停功能: 是	Start button + pause function: Yes
电机特性设置	Motor characteristics setting	使用外部手动按键: 是	Use external manual key: Yes
轨迹拆分精度(毫米): 0.30000	Track split precision (mm)	输出端口配置: ...	Input port configuration
拐角减速系数: 10.0000	Corner deceleration coefficient	输入端口配置: ...	Output port configuration
停止按钮抬起复位: 否	Stop button lift reset: No		

下页 页: 01 / 02 **确定** **取消**

Next

Page 01/02

OK

Cancel

厂商参数设置

语言选择:

教导模式:

是否使用双工位:

双工位使用不同Y轴:

参数恢复到出厂设置:

上页 页: 02 / 02 **确定** **取消**

厂商参数设置	Factory parameters settings
语言选择: 中文	Voice selection: Chinese
教导模式: 模式1	Teaching mode: Mode 1
是否使用双工位: 是	Whether use double station: Yes
双工位使用不同Y轴: 使用不同Y轴	Double station use different Y axes: Yes
参数恢复到出厂设置: ...	Reset parameters:

上页 页: 02 / 02 **确定** **取消**

Back

Page 02/02

OK

Cancel

- Password for factory parameter settings: This password is required when entering into the factory parameter settings interface. You can enter the interface directly if it is empty.
- Motor characteristic settings: Including some parameters related to motor hardware

Select Motor characteristic, and then press Enter to enter the corresponding interface:

X轴特性	Y轴特性	Z轴特性
每转脉冲(脉冲):	12800	原点开关有效电平: 低电平
脉冲当量(毫米/脉冲):	0.004675	限位开关有效电平: 低电平
脉冲当量设置向导	...	有效行程(毫米): 280.0000
复位模式:	往复	最大速度(毫米/秒): 300.0000
复位方向:	左	使用正负限位方式: 正负都使用
下页 页: 01 / 02 确定 取消		

X轴特性	Y轴特性	Z轴特性
------	------	------

X-axis characteristic/Y-axis characteristic/Z-axis characteristic

每转脉冲(脉冲):	原点开关有效电平: 低电平
Pulse per round (pulse):	Origin switch effective level: Low
脉冲当量(毫米/脉冲):	限位开关有效电平: 低电平
Pulse equivalent (mm/pulse)	Limit switch effective level: Low
脉冲当量设置向导	有效行程(毫米):
Pulse equivalent setup wizard	Effective stroke (mm)
复位模式: 往复	最大速度(毫米/秒):
Reset mode: Reciprocation	Maximum speed (mm/s)
复位方向: 左	使用正负限位方式: 正负都使用
Reset direction: Left	Use positive/negative limit mode: Both

下页	页: 01 / 02	确定	取消
----	------------	----	----

Next

Page 01/02

OK

Cancel

X轴特性	Y轴特性	Z轴特性
是否使用原点限位 是		
上页 页: 02 / 02 确定 取消		

X轴特性	Y轴特性	Z轴特性
是否使用原点限位 是		

X-axis characteristic/Y-axis characteristic/Z-axis characteristic

是否使用原点限位	是
----------	--------------------------------

Whether use origin limit: Yes

上页	页: 02 / 02	确定	取消
-----------------	-------------------------	-----------------	-----------------

Back

Page 02/02

OK

Cancel

- 1) Pulse per round (PPR): it means the number of pulses required for the motor to turn one round.
- 2) Millimeter per pulse (MMPP): refers actual distance corresponding to a pulse of the motor.
- 3) MMPP Setup Wizard: Get two points on the platform, then measure the actual distance to calculate the PPR.

X轴脉冲当量设置向导					
该向导教导平台上两个点, 根据测量出来的两个点的距离(指定轴)自动计算脉冲当量的值. 第一步: 将电机移动到第一个点, 并标记好该位置, 按键进入下一步.					
X 正转	X 反转	速度(Hz):	001000	+	-
Y 正转	Y 反转	速度(Hz):	001000	+	-
Z 正转	Z 反转	速度(Hz):	001000	+	-
下一步				退出	

X轴脉冲当量设置向导


X-axis pulse equivalent setup wizard

该向导教导平台上两个点, 根据测量出来的两个点的距离(指定轴)自动计算脉冲当量的值. 第一步: 将电机移动到第一个点, 并标记好该位置, 按键进入下一步.
--

The teaching platform has two points. The pulse equivalent is calculated according to the measured distance


between the two points (specified axis).

Step 1: move the motor to the first point, mark this position, and then press the key to enter next step.



Next

Exit



X轴脉冲当量设置向导

X-axis pulse equivalent setup wizard

第二步: 将电机移动到第二个点, 并标记好该位置, 按键进入下一步或返回上一步。

Step 2: move the motor to the second point, mark this position, and then press the key to enter next step or return to previous step.



X forward X reverse Speed (Hz)

Y forward Y reverse Speed (Hz)


Z forward Z reverse Speed (Hz)



Back


Next

Exit



X轴脉冲当量设置向导

X-axis pulse equivalent setup wizard



Step 3: Measure the distance between the first point and the second point, and press the key to return to previous step.

Step 4: Input the measured distance. Press OK to finish setting, or press the Exit key to exit.



Please enter the distance between the first point and the second point (mm):



Back


Done

Exit

- 4) Reset Mode: There are three modes to select: Line, Circle, Do not reset. Line is generally used for reciprocating screw, belt and other drive mode; Circle is generally used for dial cam transmission mode, choose Don't Reset, reset directly to the current position as the origin.
- 5) Reset direction: Please make sure the directions for movement of the motor and the manual button that on hand-held box are on the same direction before setting this parameter when you teach.
- 6) Origin sensor electrical level: Checking in the hardware test to find the effective level of the origin. When the motor is not at the origin, if the corresponding input signal level is low, then the effective switch level of origin is high, and versa level is low.
- 7) Limit sensor electrical level: checking in the hardware test to confirm the effective limit level. When the motor is not at the origin, if the corresponding input signal level is low, then the effective level is high, the contrary was low. The parameter modifications will not take effect until the controller is restart.
- 8) Effective stroke: This parameter will affect the scope of graphical display and the area where motor can move to when you teach, if can not pre-determine the effective stroke, you can enter the editing interface to move the motor manually, and then by checking the coordinate value, you can determine the motor's effective stroke.

- 9) Maximum speed: stepping motor's maximum speed is generally 15 r/s, the servo motor's maximum speed is generally 50 r/s, the actual value need to be tested before determination.
 - 10) Use limit mode: There are four ways, 1) Used all; 2) Used limit+; 3) Used limit-; 4)Used none; the input that is not used for limit can be used as general input.
 - 11) Use ORG limit or not: The default case is using origin limit function; the limit direction is determined by the movement direction of axis. If the effective stroke is positive to the origin, then it moves to negative will touch the limit of the origin. If the effective stroke is negative to the origin, then move forward to touch the origin limit.
- Track split precision: The controller splits all the graphics into tiny segments of equal length. The track split precision is the length of a tiny segment. Too small the value may affect the effect of controller motion. It is recommended to set the value to be larger than the moving distance of 1/50 round of motor turning.
 - Reset when STOP key up: Whether motor reset the same time as stop button is up.
 - Save position when move: The position will be saved if this function is active when the power is down, and begin with the saved position if restart (no corresponding key yet), this function has a certain influence to the path display and external key response.
 - Start/Pause key: While in processing state, if press the start button again, the process will pause.
 - Use external manual key: if set to yes, DI16~DI23 will be used as XYZ manual control key interfaces and teaching keys.
 - Output port config: you can set the corresponding output port number which is frequently used, set to -1 to turn off the feature
 - 1) Port number of working led: the output signal is low when program is stopped or dispensing, and run-time output is high.
 - 2) Port number of alarm led: indicates abnormal status in parameter set
 - 3) Jet up/down: when the gun is cylinder mode you need to configure this parameter, otherwise set to -1.
 - 4) STOP signal output: if emergency stop button is pressed, the output signal is high, output is not low until reset again, the signal can be used for axes lock
 - 5) Output when Reset is over: output is high after completion of reset, and the output signal is low after pressing the emergency stop.
 - 6) Output when stay at stop position: the output signal is high when motor is at the stop position, output is low while moving.
 - 7) Jet 1-8 port: corresponding to open and close of glue gun 1-8.
 - 8) Switch jet 1-8 port: corresponding to switch signal of glue gun 1-8.
 - Input port config: You can set corresponding port number that is frequently used input function, set to -1 to turn off the feature.
 - 1) STEP key: This button execute a single step process
 - 2) Alarm signal input: When this signal is low, it will stop processing and generate an alarm output.
 - 3) OFFSET key: if this button is first pressed, XY will move to needle position, and pressed again within 3 seconds, Z-axis will move to position of the needle.
 - 4) Go to end position: This button is pressed, move to set the stop position (in the system parameter settings)
 - 5) Loop work button: When this button is pressed down, the state is circulation process, and up is single process state.
 - 6) External glue gun control button: press this button to open all set glue gun ports.
 - 7) Jet down sensor: If use cylinder mode, corresponding to the gun arrive signal
 - 8) Jet up sensor: If use cylinder mode, corresponding to the gun back signal
 - 9) Up/down sensor electrical level: low or high
 - 10) Jet 1-8 open sensor: The signal will be detected before opening gun if use the signal, it will not move until the signal is valid

- 11) Jet 1-8 close sensor: The signal will be detected before closing gun if use the signal, it will not move until the signal is valid
- 12) Open/close electrical level: low or high
- 13) Switch jet 1-8 on sensor: if more than one epoxy glue gun are in use, the signal is detected before the gun advance, it won't move until the signal is valid.
- 14) Switch jet 1-8 off sensor: if more than one epoxy glue gun are in use, the signal is detected before the gun retreat, it won't move until the signal is valid.
- 15) Switch on/off electrical level: low or high
- 16) Start work for layer 1-8: when epoxy glue gun on multiple stratified operation, use the specified start processing signal to select a certain layer. glue gun hierarchical setting is in file parameter setting, select the "The layer of jet belong setting"
- 17) Quick select file key 1-8: Use specified start signal to select specified file quickly, and the keys 1~8 correspond to the processing files 0~7.
- 18) BCD switch begin port(used 8 port): You can use the BCD8421 two DIP switches to select file, the switches were occupied by two DIP switch 8 consecutive input points, such as input the starting point is set to 17, the wiring is as follows:



高位 低位
 High Low

拨码开关
 控制器
 DIP switch
 Controller

- Language select: English or Chinese
- Teach Mode: There are two modes: Mode 1: Press the speed key down is high-speed, and button up is low speed; Mode 2: Press the button down is high speed, and press again to switch to low speed
- Whether use double station: the default option is No, i.e. use single station. If it is yes, the system uses double station.
- Double station use different Y axes: when the system uses double station, this parameter determines whether the second axis of station 2 is Y axis or U axis.
- Reset all parameters to default: the vendor parameters, system parameters, user parameters to the factory settings.

2.6 Step 6: Setting system parameters

In the main interface, press "System settings" -> "System parameter settings" to enter the interface of system parameters setting:



系统参数设置

System parameter settings

User password management	G code tool relation setting
Motor parameter setting	File number correspondence
Jet offset setting	Initial file number correspondence
PLT file conversion ratio	Debugging switch: OFF
PLT tool relation setting	Origin test before running: First time
Next	Page 01/02
OK	Cancel

系统参数设置			
上电自动复位间隔 时间(秒):	-1.00000	自动滴胶开胶时间 (秒):	0.000000
进枪延时(秒):	0.000000	自动滴胶胶枪选择	...
退枪延时(秒):	0.000000	复位后回停止位置	否
换枪延时(秒):	0.000000	停止位置设置	...
自动滴胶等待时间 (秒):	0.000000	设置颜色	...
上页 页: 02/02 确定 取消			

系统参数设置

System parameter settings

上电自动复位间隔 时间(秒):	自动滴胶开胶时间 (秒):
Reset interval automatically (sec)	Auto dispensing time (sec):
进枪延时(秒):	自动滴胶胶枪选择
Jet up delay (sec)	Auto jet selection
退枪延时(秒):	复位后回停止位置 否
Jet down delay (sec)	Back to stop position after reset: No
换枪延时(秒):	停止位置设置
Jet change delay (sec)	Stop position setting
自动滴胶等待时间 (秒):	设置颜色
Auto dispensing waiting time (sec)	Color setting
上页 页: 02/02 确定 取消	
Back	Page 02/02 OK Cancel

- User Password Management: You can set the administrator password, and Grade 1/2/3 password, the priority level of which is descending accordingly. System parameter settings and the file management require the administrative password; processing parameter settings require Grade-1 password; file parameter settings, file edition, and PLT file, TCF file and G-code file conversion require Grade-2 password; file parameter setting and processing file selection require Grade-3 password.

用户密码管理	
管理员密码:	
一级密码:	
二级密码:	
三级密码:	
页: 01 / 01 确定 取消	

用户密码管理

User password management

管理员密码:

Administrator password:

一级密码:

Level-1 password:

二级密码:

Level-2 password:

三级密码:

Level-3 password:

页: 01 / 01

确定

取消

Page 01/01

OK Cancel

- Motor Parameter Settings: Set parameters related to motor speed.

X轴参数	Y轴参数	Z轴参数	
起步速度(毫米/秒):	10.00000	复位高速(毫米/秒):	100.0000
手动低速(毫米/秒):	10.00000	复位加速时间(秒):	0.050000
手动高速(毫米/秒):	70.00000	手动微调脉冲数:	5
空移加速时间(秒):	0.050000		
复位低速(毫米/秒):	10.00000		
页: 01 / 01 确定 取消			



X-axis parameters/Y-axis parameters/Z-axis parameters



Start speed (mm/sec)

Reset high speed (mm/sec)



Manual low speed (mm/sec)

Reset acceleration time (sec)



Manual high speed (mm/sec)

Manual trimming pulses



Shift acceleration time (sec)



Reset low speed (mm/sec)



Page 01/01

OK

Cancel

- 1) Start speed: normal speed of the stepper motor should be less than the initial 3 r/s, and the servo motor is less than 5 r/s.
- 2) Manual low speed: for precise location when teach manually
- 3) Manual high speed: for quick location when teach manually
- 4) Pass accelerated time: the time from start speed to shift speed, the smaller the value is, the faster the speed. If set to 0, it will move on average speed.
- 5) Reset low speed: for precise location when reset
- 6) Reset high speed: for quick location when reset
- 7) Reset accelerated time: the time from reset low speed to reset high speed, the smaller the value is, the faster the speed. If set to 0, it will move on average speed.
- 8) Vernier regulation pulse: when move the axis manually, press the movement button one time, the number of pulses will be emitted by the system correspondingly.
- 9) Manual fine-tuning pulses: each fast axis movement key is pressed, the number of pulses emitted by the system when the motion key of each axis is pressed quickly during manual control of the motion of each axis.

- Jet offset Settings: The relative position of the eight glue-guns has offset. You can use this function to set the position offset.

胶枪偏移设置			
教导胶枪基准点	...	胶枪5偏移设置	...
胶枪1偏移设置	...	胶枪6偏移设置	...
胶枪2偏移设置	...	胶枪7偏移设置	...
胶枪3偏移设置	...	胶枪8偏移设置	...
胶枪4偏移设置	...		

页: 01 / 01

确定 取消

胶枪偏移设置

Jet offset settings

教导胶枪基准点

Teach jet reference point

胶枪1偏移设置

Jet 1 offset setting

胶枪2偏移设置

Jet 2 offset setting

胶枪3偏移设置

Jet 3 offset setting

胶枪4偏移设置

Jet 4 offset setting

页: 01 / 01

确定 取消

Page 01/01

OK Cancel

Set a reference point first, move each glue gun to the reference point manually to compare and get the offset.

胶枪偏移设置			
教导胶枪基准点	教导胶枪基准点	...	
胶枪1偏移设置	手动控制胶枪移动到基准点, 按教导键教导, 按删除键清零.	...	
胶枪2偏移设置	基准点X坐标: 0.00000	...	
胶枪3偏移设置	基准点Y坐标: 0.00000	...	
胶枪4偏移设置	基准点Z坐标: 0.00000	...	

页: 01 / 01

确定 取消

教导胶枪基准点

Teach jet reference point

手动控制胶枪移动到基准点, 按教导键教导, 按删除键清零.

Manually move the jet to the reference point, press the Teach key to teach, or press the Delete key to clear.

基准点X坐标: 0.00000
基准点Y坐标: 0.00000
基准点Z坐标: 0.00000

Reference point X coordinates:

Reference point Y coordinates:

Reference point Z coordinates:

设置 删除 教导 退出

Setup Delete Teach Exit

- PLT file transfer ratio: Because the coordinate unit of PLT file is different from that of the processing file, you need to multiply the conversion proportion to adjust it. The actual value is related to the settings of software generating PLT files.
- PLT pen relation setting: Pen of each color in PLT file corresponds to a pen number. There are eight glue guns, glue gun 1 to 8, in the processing files. This function is used to set the corresponding relationship of pen number and glue gun number.
- G code knife relation setting: Set the corresponding relationship of G-code knife number and glue gun.
- Set file table: There are 100 file numbers in total, each of which is corresponding to a processing file. When using expanded display panel, you can select the corresponding processing file by selecting the file number.
- Initialize file table: rearrange the file numbers
- Debug switch: In general processing, please set this parameter to off; otherwise, it will influence the processing effect.
- Check origin before running: available options are "No", "First time" and "Every time". If "No" is selected, the system considers that it has been reset before every processing; if "First time" is selected, the system checks whether it has been reset before the first processing; if "Every time" is selected, the system checks whether it has been reset every time before processing. During processing, press the emergency stop button and it requires resetting.
- Auto reset interval: The controller is reset automatically after a while once electrified. Auto reset is not performed if this parameter is of negative value.
- Jet down delay/Jet up delay: If the "Factory parameter setting"/"Output port config"/"Jet up/down" is set to a non-negative, then the gun up and down delay becomes effective. This signal will restrict the cylinder action together with the "Jet down sensor" and "Jet up sensor", waiting for the sensor arrive and the wait time should not less than the set delay time before the next gun action.
- Switch jet delay: Response time for switch gun action, and for the gun up/down sensor will restrict gun switch action, waiting for the gun up/down sensor and wait time should no less than the set delay action when the time for the next step.
- Wait time of auto drip: if the set time is up and there is no operation, it will dispense automatically.
- Time of auto drip: the time for opening the gun when automatic dispensing
- Select auto drip jet number: select automatic dispensing of glue gun.
- Go to stop pos after reset: If set to "Yes", then it will move to the set position after reset.
- Stop position setting: you can set a stop position, use "Factory parameter setting"/"Go to the end position" to

move to the stop position

- Set color: totally 16 colors are available; “color 01” is the background color, “color 02” ~ “color 06” are keys’ color, and “color 07” ~ “color 16” are reserved.

2.7 Step 7: Setting user parameters

In the main interface, press “System settings” -> “User parameter settings” to enter the interface of user parameters setting:

User parameter settings

Cycle processing times:

Cycle processing interval (sec):

Auto reset interval times

Whether process in cycle: No

Number of cycle processing files

Page 01/01

OK Cancel

- Cycle processing times: the times of cycle processing
- Cycle processing interval: the interval of cycle processing
- Automatically reset interval times: processing times before automatic reset

- Whether cycle processing: select “Yes” for cycle processing, or select “No” for single processing
- Cycle processing file number: the number of files that will be processed; if it is set to "0", and only process the current file; if it is set to nonzero digit, the files from No. 0 to the setting number minus 1 will be processed; the setting number doesn't exceed 8.

2.8 Step 8: Setting processing parameters

In main interface, press “System settings” -> “Processing parameter settings” to enter the interface of processing parameters setting:



加工参数设置

Processing parameter settings

X轴空移速度(毫米/秒):

X-axis shift speed (mm/sec):

Y轴空移速度(毫米/秒):

Y-axis shift speed (mm/sec):

Z轴下降速度(毫米/秒):

Z-axis down speed (mm/sec):

Z轴抬起速度(毫米/秒):

Z-axis up speed (mm/sec):

Z轴抬起加速时间(秒):

Z-axis accelerated up time (sec):

页: 01/01 确定 取消

Page 01/01

OK Cancel

- X-axis space shift speed: quick positioning speed of X-axis

- Y-axis space shift speed: quick positioning speed of Y-axis
- Z-axis move down speed: quick downwards positioning speed of Z-axis
- Z-axis move up speed: quick upwards positioning speed of Z-axis
- Z-axis accelerated up time: It is the required time for changing from start speed to fast location speed. The smaller the value is, and the faster of speed change will be. If it is set to be 0, it means on average velocity.

2.9 Step 9: Choosing/Creating processing file

In main interface, press the file name or “Select file” to enter the processing file selection interface:



选择加工文件 [DJJ]

Select processing file [DJJ]



Copy Paste Delete New Up




Page up



Page down



Previous



Open



Back

Click the selected file, press “Open” key to select the file, or press “Return” to give up. Press “Up” to select folder or disk.

Press the “Preview” key to preview the file:



加工文件预览

Processing file preview

视口左移

Move left

视口右移

Move right

视口前移

Move front

视口后移

Move back

图形缩小

Zoom out

图形放大

Zoom in


默认大小

Default size

退出

Exit

In processing file selection interface, press “New” to create a file:



Please enter the new file name:



OK Cancel

When you have finished the input of file name and file number, you can press OK to generate a processing file with a “.DJJ” suffix.

Note: The operation of processing file selection only applies to the files in local disk (ADT-TP3540). To process files in removable disk (USB drive), please copy the files to local disk through file manager (pressing “File manager” -> “File operation” key in main interface); to delete the file, enter file manager (pressing “File manager” -> “File operation” key in main interface).

2.10 Step 10: Setting file parameters

In main interface, press “Parameter settings” to enter the interface of file parameter setting:

文件参数设置			
当前工位对针点	...	滞后开胶延时(秒)	0.000000
轨迹速度(毫米/秒):	100.0000	提前关胶距离(毫米):	0.000000
轨迹加速时间(秒)	0.100000	拉丝高度(毫米):	0.000000
开胶延时(秒):	0.000000	拉丝速度(毫米/秒):	10.00000
关胶延时(秒):	0.000000	拉丝延时(秒):	0.000000
下页		页: 01/02	确定 取消

文件参数设置

File parameter settings

当前工位对针点	滞后开胶延时(秒)
Current station pin point	Lag open jet delay (sec)
轨迹速度(毫米/秒):	提前关胶距离(毫米):
Track speed (mm/sec)	Close jet distance in advance (mm)
轨迹加速时间(秒)	拉丝高度(毫米):
Track acceleration time (sec)	Drawbench height (mm)
开胶延时(秒):	拉丝速度(毫米/秒):
Open jet delay (sec)	Drawbench speed (mm/sec)
关胶延时(秒):	拉丝延时(秒):
Close jet delay (sec)	Drawbench delay (sec)
下页	页: 01/02 确定 取消
Next	Page 01/02 OK Cancel

文件参数设置

File parameter settings



Jet layer setting



Back to stop position after processing: No



File number correspondence



Clear current output



Clear total output



Back


Page 02/02

OK

Cancel


Each file has independent file parameters.

- Base position setting: set the base position of the process file, the default starting point of the file is the first point.



工位一对针位置设置


Station 1 tool aligning position setting



The tool aligning point hasn't been set.

The start point of processing file is used as the aligning point by default

[Position] Move to aligning point, and press Z axis down again in three seconds



Position	Set	Adjust
Reset	Stop	Teach



Exit

- Track speed: The track speed of process
- Track acceleration time: It is the time needed to change from starting speed to track speed. The smaller the value is, the faster the speed change will be. If it is set to be 0, it is processed on average of track speed.
- Open jet delay: responding time before opening glue gun
- Close jet delay: responding time before closing glue gun
- Lag open jet delay: It is the delay time before opening glue gun if lag open jet is used.
- Close jet distance in adv.: It is the distance before closing glue gun in advance if close jet in advance feature is used.
- Drawbench height: When the jet is up, it will move back at a low speed for a tiny distance, and then continue to move back. If set to 0, this function is invalid
- Drawbench speed: The speed is generally set relatively small, so that it can draw slowly.
- Drawbench delay: reach the drawbench height, pause for some time and then continue to back the gun.
- The layer of jet belong setting: Epoxy drip always use this parameter to select the layer in which is to drip (1 to 8 layers), the parameter can be input by factory configuration settings to select the corresponding input

signal to process a single layer.

- Go to end pos when stop: If set to "Yes", after finish processing the file, it will move back to the stop position which is set before.
- Set file table: View and set the corresponding file number to the file. This function is convenient to choose files in numerical way.
- Clear current output: Clear the current output of the current station, and start re-count.
- Clear total output: Clear the total output of the current station, and start re-count.

2.11 Step 11: Editing files

In main interface, press "Edit file" to enter the file editorial interface:




Page up

Page down

Specify point



Start point



Straight line



Lag open jet: No

速度:

Speed

类型 定位 插入

Type Position Insert

针高

Needle height

教导

Teach

直线 平移 删除

Straight line Shift Delete

圆弧 缩放 保存

Arc Zoom Save


单点 高级 退出

Single point Advance Exit

For detailed functions of file edition, please see Chapter III “*Details of File Edition*”.

2.12 Step 12: Processing operation

In main interface, press “Processing operation” to start the processing; in double station, press on the view area to switch between output and view.



工位一

Station 1



Select file

Parameter Settings

File Edit

Align Tool

Process




Processing time



Current instruction:

Current state:



Single step running

Disable open glue



System Settings / File Manager



Hardware Test / Version Info



Reset / Pause / Stop



工位一

Station 1




- Select file
- Parameter Settings
- File Edit
- Align Tool
- Process

工位二


Station 2



Processing time



- Current instruction:
- Current state:



- Single step running
- Disable open glue



System Settings / File Manager



Hardware Test / Version Info



Reset / Pause / Stop

- Station 1 (2): open and close the corresponding station.
- File name/file selection: two key functions are to enter the file selection interface.
- Parameter settings: press the key to enter the processing file parameter settings.
- File edit: press the key to enter the processing file editing.
- Base position: press the key to locate the base position of corresponding station.
- Processing operation: press the key to start processing.

- System settings: press the key to enter the setup interface of the factory parameters, system parameters, user parameters, and processing parameters.
- File manager: press the key to enter the file operation interface.
- Hardware test: press the key to enter the hardware test interface.
- Version information: press the key to check the program version information.


- Reset: Press the key to reset
- Pause: Press the key to pause
- Stop: Press the key to stop
- Single-step operation: press the key to switch between automatic and single step. In single-step mode, press once to start running one processing point; in automatic mode, run the processing points in sequence automatically.
- Disable dispensing: press the key to enable or disable dispensing.

- Cycle mode: the display mode is cycle or single, which is set in "System Settings" -> user parameters.
- Cycles: display the current set cycle processing times, which is set in "System Settings" -> user parameters.
- Current times: display the current cycle processing times of the corresponding station, which can be cleared in the "Parameter settings" - Clear station production.
- Total amount of processing: display the current processing amount of the corresponding station, which can be cleared in the "Parameter settings" - Clear station production.
- Processing time: display the processing time of the corresponding station.

- Status: the current operating status, there are such status like "RUN", "STOP", "PAUSE", "RESET", "Dispense" etc.
- Current instruction: the instruction number of the current processing and processing location points.
- The processing error displays in the column on the left of the current instruction. Processing graphics and processing trajectory are displayed in the upper right.

3 Details of File Edition

3.1 File editing interface



选中指令点右侧
可显示参数信息

Select the right side of the instruction point to show the parameter information

可直接编辑指令
点坐标等参数

Edit the instruction point coordinates and other parameters directly

加工点
参数信息

Processing point parameter information

指令点
上下翻页
按下0.5s
可连续翻
页

Turn pages of processing points

Press and hold 0.5sec to turn pages consecutively

输入跳
转到指
定点

Input and go to specified point

定位到
当前指
令点

Locate current instruction point

图形平移到当前位置

Shift graph to current position

选择指令点类型

Select type of instruction point

缩放图形

Zoom in/out graph

高级编辑功能

Advanced edit function

在当前指令之前插入一个指令点

Insert an instruction point before current instruction

删除当前指令点

Delete current instruction point

将Z轴坐标设置为针高

Set Z-axis coordinates to needle height

轴手动控制

Manual axis control

图形、轨迹显示区

Graph, track display area

轴坐标显示

Axis coordinate display

将当前轴位置教导到当前指令点中

Teach current axis position to current instruction point

上一页

下一页

指定点

Page up

Page down

Specify point

起 点

Start point

直 线

Straight line

滞后开胶: 否

Lag open jet: No

速度:

Speed



Type Position Insert



Needle height



Teach



Straight line Shift Delete



Arc Zoom Save



Single point Advance Exit

- XY axis manual shift key will be hidden after a certain period of time after the operation, and press the corresponding position again to show.
- XYZU motor manual key: Manually move the motor; jog speed points, manual low speed, manual high-speed (set in the system parameters); speed switching is determined by pressing time, click for jogging, or press and hold for 0.15~2.15 seconds is manual low speed, press and hold for 2.15 seconds is manual high speed.
- Teach key: save the current coordinates to the current point and skip to the next point
- Pin height key: save Z coordinates to the pin height parameters of the current point; end point and single-point instructions have pin height parameters.
- Insert key: Insert a point before the current point.
- Delete key: delete the current point
- Save key: save the modified file. The key is invalid and dark if the file has not been modified; if the file is modified, the modification can be saved
- Exit key: Exit the editing interface
- Positioning key: position the motor to the current point
- Shift key: shift the graph; this function is used to adjust the XY coordinates of the graphs. Determine the starting point of the graph first, and then move the XY coordinates to desired position; after the function is called, the entire graph is automatically shifted to the current location.
- Zoom key: This function is mainly used for unified zooming in and out of XY coordinates. Different to the bulk edit mode, the function will also zoom in and out the radius of the arc and ellipse.
- Advance key: advanced editing features
- Type key: select the type of processing points
- Straight line key: switch type (starting point / straight line / end point)
- Arc key: switch type (arc / full circle / arc endpoint)
- Single point key: switch type (single point / null shift)

- Previous key: turn to previous page of processing points
- Next key: turn to next page of processing points
- Go-to key: go to a specified processing point
- Selection keys of 5 processing points, edit box keys of 8 (the number of keys depends on the type of processing point) processing point parameters

3.2 Selecting type of processing instruction

In file editing interface, press the “Type” key to pop up the interface for selecting type of processing point, and click the keys to select instructions.



选择加工点类型

Select the type of processing point



Motor reset Port output Wait for input




Delay pause Select jet Jet control



Define label Set speed Processing end



Call program Call file Go-to program



Set offset Increase offset Reference point



Page up Page down Page 01/02 Help Cancel



选择加工点类型

Select the type of processing point



Set start point Start point End point



Straight line Single point Shift



CW arc CCW arc Arc



Circle Arc end CW oval



CCW oval Oval end



Page up Page down Page 02/02 Help Cancel

Press the “**Help**” key to view the description of the instruction.

- Reset: Specify one or some motors to reset; the appointed motor go on performing the next instruction after the reset
- Output: Specify some port outputs to switch on or off signal, and keep performing the next instruction after the set delay time
- Wait input: Wait for some input ports to open/close to perform the next action; delay time can be set, if it is set to be 0, it will not continue to process until the signal arrive. If delay time is not zero. If time is out to delay time, it will jump to the appointed label to start to process.
- Delay: Go on performing the next step after the set delay time; if the delay time is 0, the program is paused until Start or Pause key is pressed again.
- Select jet: Select the operating glue gun. It is default to use the first one.
- Jet control: It is capable of controlling a glue gun to open and close independently. This instruction is usually used in graph importing function. Generally, “START” and “END” or “PTP” instructions are used to control the open/close of glue gun.
- Define label: The label can be named by numbers, letters, symbols or Chinese, the program will jump to the

position where the program called or enter the corresponding label when jump.

- Set speed: in unit of mm / sec, can only set the track speed and can not set shift speed, set to 0 means to restore to the initial track speed.
- End work: This is the end of processing which the program will no longer execute.
- Function call: You can set these labels, such as "File number", "Start label", "End label", and "Call times".
 - File number: the file to be called by the program, set to null (directly press the OK button) to call the contents of this document. The correspondence of file number and file can be set in "System parameter setting"/"Set file table" or "File parameter setting"/"Set file table".
 - Start label, end label: labels must have been defined, before or after the line, or specify file to be called, if set to empty (input directly press the OK button), it means to call from the beginning of the file line to the end of the line.
 - Call times: If set to 0, it can be called unlimited.
- Call file: You can set such parameters: "File number", "Call times", "Used start pos", "X/Y/Z Start"
 - File number: the file to be called by the program, the File number can not be set to be empty. The correspondence between File number and the file can be set in "System parameter setting"/"Set file table" or "File parameter setting"/"Set file table"
 - Call times: Can be called unlimited if set to 0
 - Use start pos: The called file will adjust start position to this new position if using start position.
- Function Jump: jump to the specified label, if the label is set to be empty (directly press OK), it will jump to the end of the program.
- Set Offset: The actual position=coordinates which is set + Offset
- Add Offset: Offset increase or decrease
- Base Position: Play a role of adjusting the graphical, not add any action, it is generally defined in the start of a file for calibration.
- Adjust Start: adjust the start point of the graph which is called by the program, generally used with instruction of Function Call.
- START: It is start point of track. When process, Z-axis will move down the glue gun to the start point and open the gun. You can set whether use delay open gun at the start point. If so, it does not open the glue gun when moved to the starting point, but opening it after the set delay time. This feature is mainly to prevent piling glue at the start point.
- END: It is the end-point of track. When process, close the glue gun at the end-point, and make Z-axis return to the needle height position. A piece of graphic can have several starting points and end-points. You can set whether to close the glue gun in advance at the endpoint. If so, it will close the glue gun in advance at the set distance before the endpoint. This function is used to avoid the piling glue at the endpoint.
- LINE: Run to this coordinate with straight-line mode.
- PTP: Locate the XY quickly first, and then advance the glue gun at Z-axis. After that, open the glue gun for a while, and then close it; then, Z-axis returns to the needle height position.
- PASS: XYZ is located to this point quickly.
- CW ARC & CCW ARC: The previous point and next point must be bonded, forming a circular arc by specifying circular arc starting point, semi-diameter, and circular arc end-point.
- ARC: The previous point and next point must be bonded, forming a circular arc by specifying the starting point of circular arc, a point on the arc, and the circular arc end-point.
- CIRCLE: The previous point and next point must be bonded, forming a circular arc by specifying the starting point of circular arc, a point on the arc, and the other point on circular arc.
- END ARC: This point should follow the instruction of ARC, CW ARC, CCW ARC, and CIRCLE to bind with the previous two points to form a circular arc. If the end-point of ARC is the end-point of track, the end-point of circular arc can be replaced by "END" instruction.
- CW OVAL & CCW OVAL: The previous point and next point must be bonded, forming an oval by

specifying the starting point of oval, oval center, semi-diameter of long/short axis, and the oval end-point.

- END OVAL: This point should follow the instruction of clockwise oval and anti-clockwise oval to bind with the previous two points to form an oval. If the end-point of oval is the end-point of track, the end-point of oval can be replaced by “END” instruction.

3.3 Modifying data of processing point

There are two ways of modifying data of processing point, manual input and teach.

3.3.1 Manual input

Press the key of the processing point that needs to be modified; if the modified parameter is numerical value, you can click the edit box directly to input the number; if it has multi options, you can click the edit box to select content:




Page up

Page down

Specify point



Start point



Straight line



Lag open jet: No



Speed



Type Position Insert



Needle height



Teach



Straight line Shift Delete



Arc Zoom Save



Single point Advance Exit



Page up

Page down

Specify point



Start point



Straight line



Lag open jet: No



Speed



Type Position Insert



Needle height



Teach



Straight line Shift Delete



Arc Zoom Save



Single point Advance Exit

Click on the corresponding processing point to view the parameters of the point. You can press the page up/down key to view other processing points. Press the "Specify point" key and then input the number of a processing point to go to the processing point directly.

Note: If the file has been modified but not saved, the "Save" button will be in bright color (upper left figure), the key is valid and you can press it to save files. After saving, the "Save" button will be in dark (upper right figure), and the key is invalid.

3.3.2 Teach


Except inputting directly, the coordinates of processing point can also be input in the teach way: First, select the processing type. Only such types as "START", "LINE", "END", "PTP", "PASS", "CW ARC", "CIRCLE", "END ARC", "CW OVAL", "CCW ARC", and "END ARC" can be taught. And only the needle height of "PTP" and "END" can be taught.

Once the process point is selected, use manual key to move the motor to the target position, and press "Teach" key, the current coordinates will be saved in the processing point. For the convenience of continuous teach, the current point number will become the next one when teach key is pressed. Therefore, in order to view the teach result, you have to use Left key to return to the previous point.


When teach the needle height, select the processing type (must be "END" or "PTP"), move Z-axis to the proper needle height, and press "Height" key to save the current Z-axis coordinate in "Needle height" parameters of processing point.



Page up
Page down
Specify point



Arc end point
Arc



End point
Start point



Lag open jet: No



Speed



Type Position Insert



Needle height

教导

Teach

直线

平移

删除

Straight line

Shift

Delete

圆弧

缩放

保存

Arc

Zoom

Save

单点

高级

退出


Single point

Advance


Exit


3.4 Constraint condition for the type of processing point

- A continuous track should be started with a “Starting point”, and ended with an “End point”, which may contain processing point types such as straight line, circular arc, and oval midway.



- “Clockwise circular arc”, “Anti-clockwise circular arc”, “Circular arc”, “Circle”, “Clockwise oval”, and “Anti-clockwise oval” instructions should not be used independently, and should be combined with the previous point and the next point to form a graph.





- The End Point of "Circle" is superposed with the starting point. The "End Point" is for auxiliary effect only.



1 起点


Start point

终点

End point

2 顺椭圆

CW oval



5 终点

End point

1 起点

Start point

3 逆椭圆

CCW oval


直线

Straight line

椭圆终点

Oval end point

- The oval center and semi-diameter of long and short axes are given out by "Clockwise oval", and "Anti-clockwise oval". The coordinates of oval Starting and End Points are given out by the previous point and the next point (Because the oval starting point, end-point, and center are not convenient to regulate, you can use the "Common graph" in advanced edition to regulate a rectangle to help complete the regulation of an oval).



直线 8 终点 圆弧终点

Straight line End point Arc end point

1 起点 7

Start point

3 逆圆弧

CCW arc

6 逆圆弧

CCW arc


单点 单点
单点 单点

单点

Single point

单点

Single point



- “Anti-clockwise circular arc” and “Clockwise circular arc” instructions only specify the arc semi-diameter, and the coordinates of arc starting point and end-point. They are given out by the previous and next points.
- The semi-diameter of the “Anti-clockwise circular arc” and “Clockwise circular arc” should not be set to be less than half of distance between these two points; otherwise, it cannot form a circular arc.
- The regulation of “Single point” is much easier; however, “Single point” cannot be used combining with circular arc or oval instruction.
- “Travel” instruction means to locate the XYZ axes to the appointed coordinates swiftly at the same time without opening or closing the glue gun. “Starting point” instruction is to locate XY axes swiftly to the appointed position, and then locate the Z-axis, together with opening the glue gun.
- Only “End-point” and “Single point” can regulate the “Needle height”.

3.5 Skills for continuous teaching

To easy and convenient to finish the regulation of a graph, three switching shortcuts are set:

“Straight line” key: Switch the type of current processing point to Origin, Straight line, and End-point.

“Arc” key: Switch the type of current processing point to Arc, Circle, and Arc end-point.

“Single point” key: Switch the type of current processing point to Single point and Shift.

In addition, the software contains intelligent judgment function; it can generate the type of next point according to the type of previous point. For example, if the previous point is “Starting point”, the next point will be the “Straight line” automatically. If the previous point is “End point”, the next point will be the “Starting point”; if the previous point is “Circular arc”, the next point will be the “Circular arc end-point”; and if the previous point is “Single point”, the next point will be the “Single point”. In addition, the set parameters, such as “Single point time”, “Needle height”, and “Speed”, will be recorded automatically and applied to the next point. When inserting a new processing point, it will generate the processing point of proper type according to the types of processing point before and after.

4 Advanced Applications

4.1 Advanced editing functions

In file editing interface, you can press the “Advance” key to call the advanced edit functions:



高级编辑功能

Advanced editing function



Batch edit

Array copy

Z-axis depth



Needle lift height

Batch delete

Automatic corner



Program expand


Common graph

Find type



Local adjustment

Multiple arrays



Page up

Page down

Page 01/01

Help

Cancel

You can press corresponding key to select desired edition function.

4.1.1 Batch edit

Batch edit is used to modify large amount of data.



Batch edit



Edit range:



Start point



End point




Edit content: X coordinates



Edit condition: No



Edit mode: Specify value



Specify value

Teach



OK

Cancel

批量修改

修改范围：

起始点：00001

结束点：00019

修改内容：X坐标

修改条件：X坐标 == 0.000000

修改方式：指定数值

指定数值：0.000000

教导

确定

取消

取消

批量修改

Batch edit

修改范围：

Edit range:

起始点：00001

Start point

结束点：00019

End point

修改内容：X坐标

Edit content: X coordinates

修改条件：X坐标

Edit condition: X coordinates

修改方式：指定数值

Edit mode: Specify value

指定数值：0.000000

Specify value

Teach

确定

取消

OK


Cancel

- Modified range: Number of the start process point and end process point that need to be modified
- Modified field: Following contents are available to modify:



选择修改内容


Select edit content



- Modified condition: You can specify a certain data, and the data need to be modified to be equal to, not equal to, more than, or less than an appoint value.
- Modified mode: It includes Appointing Value, Appointing Increment, and Appointing Rate. Appointed Value means to set the modified contents as the appointed value. Appointing Increment means to add a value to the original value (if the appointed value is a negative number, it decreases the value). Appointing Rate means to multiply the original value with a value.

4.1.2 Array copy

Array copy function is used to replicate a single graph to multiple copies in the array way, it can generate a parallelogram array as well.



阵列复制

Array copy



Copy range:

Start point: End point:




Reference point (A): Locate




Groups in X direction:



Groups in Y direction:



End point coordinates in Y direction (B): Teach



End point coordinates in Y direction (C): Teach



Start direction: Word wrap mode: S OK Cancel

- Copy range: the number of start process point and end process point of graph needs to be copied
- Base point (A): It is a certain reference point on the graph needs to be copied. Teach the distance between X and Y direction needs to take this point as reference. It is default to select the first point

of the graph.

- X array number: Group numbers of the array in X direction
- Y array number: Group numbers of the array in Y direction; if you just copy once, set the group numbers in XY direction to 1.
- X end point (B): This coordinate should be the coordinate of last group in X direction that is corresponding to the reference point A.
- Y end point (B): This coordinate should be the coordinate of last group in Y direction that is corresponding to the reference point A.
- First offset: From A to B, or from A to C
- New line mode: It includes S-shape and Z-shape of changing new line. Z-shape: when the process of a line is finished, it will return to the starting point to start processing the next line. S-shape: It does not return to the starting point, but processing the next line in a turn-back way.
- Press “Position” button can locate to the reference point

4.1.3 Z-axis depth

This function is used to adjust the Z-axis coordinate and needle height uniformly. First, confirm the starting point of the graph, and then move Z-axis to Z coordinate that the point needs to adjust. After having applied this function, the Z-axis coordinates and the needle height of the whole graph will be adjusted according to the value of Z-axis. (The needle height after shifted shouldn't exceed the limit, or else it can't run normally and will cause overrun errors)

4.1.4 Needle height

This function changes the value of needle height by way of relative to Z-axis coordinate.

For example, the processing point type of a point is “PTP”, Z-axis coordinate is -70, if you set the needle lifting height to be 30, the needle height of this point is then changed to $(-70+30) = -40$.

4.1.5 Batch delete

Select the range of processing points that need to be deleted, and press OK to delete.

4.1.6 Automatic corner

This function is used to change the break angle to circular arc. The arc length of circular arc can be set. If the side length of these two break angles is not enough for changing to the set arc length, the fillet arc length will be reduced automatically to fit for the side length of break angle.





Automatic corner



Edit range:



Start point:



End point:



Corner arc length:



Note: before edit, please save or back up the original file



OK

Cancel



Page up

Page down

Specify point



End point



Straight line

针高:	-20.000
提前关胶:	否

Needle height:
Close jet in advance: No

速度:

Speed

类型	定位	插入
----	----	----

Type Position Insert

针高

Needle height

教导

Teach

直线	平移	删除
----	----	----

Straight line Shift Delete

圆弧	缩放	保存
----	----	----

Arc Zoom Save

单点	高级	退出
----	----	----

Single point Advance Exit

上一页	1-选择胶枪	胶枪1:	☒	胶枪5:	关
	2-起 点	胶枪2:	关	胶枪6:	关
下一页	3-直 线	胶枪3:	关	胶枪7:	关
	4-逆 圆 弧	胶枪4:	关	胶枪8:	关
指定点	5-直 线				
X: 20.020 Y: 20.000 Z: -30.000					
类型	定位	插入	针高	教导	
直线	平移	删除			
圆弧	缩放	保存			
单点	高级	退出			

上一页
下一页
指定点

Page up

Page down
Specify point

[-选择胶枪

[-起 点

[-直 线

[-逆 圆 弧

[-直 线

Select jet

Start point

Straight line

CWW arc

Straight line

胶枪1:		胶枪5:	关
胶枪2:	关	胶枪6:	关
胶枪3:	关	胶枪7:	关
胶枪4:	关	胶枪8:	关

Jet 1: On Jet 5: Off
Jet 2: Off Jet 6: Off
Jet 3: Off Jet 7: Off
Jet 4: Off Jet 8: Off

类型 定位 插入

Type Position Insert

针高

Needle height

教导

Teach

直线 平移 删除

Straight line Shift Delete

圆弧 缩放 保存

Arc Zoom Save

单点 高级 退出

Single point Advance Exit

Before performing automatic corner

After performing automatic corner

4.1.7 Extend program

This function will extend the instruction of "Function call" and "Call file" which is available for selection, and directly insert into the location of the instruction. Note that instruction whose call time is 0 can not be carried out.

4.1.8 Graphics library

The common graphics interface is shown below:



Select graph



Test graph Oval Runway Rectangle fill



Circle fill Corner rectangle



Page up Page down Page 01/01 Help Cancel


- Test graph
 - Step 1: Select a plane for the test graph
 - Step 2: Input the length of the side
 - Step 3: Teach coordinates of the third axis
 - Step 4: Generate the following graph



Page up
Page down
Specify point



Start point



Straight line



Lag open jet: No



Speed



Type Position Insert



Needle height



Teach



Straight line Shift Delete



Arc Zoom Save



Single point Advance Exit

You can move the graph to a proper position by functions of graph shift or batch edit.

- Oval




Generate oval



Left vertex: Teach




Right vertex: Teach



Top vertex: Teach




Bottom vertex: Teach



Start point: Teach



End point: Teach



Oval direction: CW



OK Cancel



Page up
Page down
Specify point



Select jet
Start point
CW oval
End point



Lag open jet: No



Speed



Type Position Insert



Needle height



Teach



Straight line Shift Delete



Arc Zoom Save



Single point Advance Exit

Generated oval graph

Press the Teach key in the interface of oval to teach all vertexes of the oval (to generate an oval, you need to regulate at least one vertex at both X and Y directions). Once starting point and end point have been taught, select the oval direction, and then press OK to generate the oval. The data of all vertexes in this interface are saved at all times, even you exit the interface. Therefore, you can exit midway while teaching the oval and the data will still be there when you re-enter.

- Runway

生成跑道

Generate runway

Left vertex: Teach

Right vertex: Teach

Top vertex: Teach

Bottom vertex: Teach

Start point: left or bottom center point

跑道方向: 顺时针

Runway direction: CW

确定 取消

OK Cancel

上一页	1-起 点	X: 38.0311	滞后开胶: 否
	2-直 线	Y: 204.302	
下一页	3-圆 弧	Z: -80.942	
	4-圆弧终点	速度: 100	
指定点	5-直 线		

X: 0.000 Y: -0.050 Z: 0.000

类型	定位	插入	针高	教导
直线	平移	删除	↑ Z	
圆弧	缩放	保存	↓ Z	
单点	高级	退出		

上一页

下一页

指定点

Page up

Page down

Specify point

起 点

-直 线

-圆 弧

-圆弧终点

-直 线

Start point

Straight line

Arc

Arc end point

Straight line

滞后开胶: 否

Lag open jet: No

速度:

Speed

类型 定位 插入

Type Position Insert

针高

Needle height

教导

Teach

直线 平移 删除

Straight line Shift Delete

圆弧 缩放 保存

Arc Zoom Save

单点 高级 退出

Single point Advance Exit

Generated runway graph

Press the Teach key in the interface of generated track to teach all vertexes of the track. Select the starting point (the starting point can only occur in the middle of the long side), select the track direction, and press OK to generate the track. The data of all vertexes in this interface are saved at all times, even you exit the interface. Therefore, you can exit midway while teaching the oval and the data will still be there when you re-enter.

● Rectangle fill

矩形填充

上顶点: 0.00000 0.00000 教导

下顶点: 0.00000 0.00000 教导

胶枪直径: 0.00000

填充样式: 纵向填充

确定 取消

矩形填充

Rectangle fill

上顶点: 0.00000 0.00000 教导

Top vertex:

Teach

下顶点: 0.00000 0.00000 教导

Bottom vertex: Teach

Jet diameter:

Fill type: Vertical

OK Cancel

上一页

下一页

指定点

1-起 点

2-直 线

3-直 线

4-直 线

5-直 线

X: 55.2000

Y: 46.6000

Z: -80.372

速度: 100

滞后开胶: 否

X: 27.600 Y: 23.300 Z: 0.000

类型

定位

插入

直线

平移

删除

圆弧

缩放

保存

单点

高级

退出

针高

↑Z

↓Z

教导

↺

↻

上一页

下一页

指定点

Page up

Page down

Specify point

起 点

Start point

直 线

Straight line

滞后开胶: 否

Lag open jet: No

速度:

Speed

类型

定位

插入

Type Position Insert

针高

Needle height

教导

Teach



Straight line Shift Delete



Arc Zoom Save




Single point Advance Exit

Generated rectangle fill graph

Teach the diagonal points of the rectangle, and the rectangle fill graphic will be generated automatically. If the diameter of the glue gun can not be divisible by the length of the side, there will be indicative messages which show that whether to enlarge or reduce the diameter of the glue gun so that it will be divisible by the length of side.

- Circle fill



Circle fill



First point on circle: Teach



Second point on circle: Teach



Third point on circle: Teach



Jet diameter:



OK Cancel



Page up
Page down
Specify point



Start point
CCW arc
Arc end point
CCW arc
Arc end point



Lag open jet: No



Speed



Type Position Insert



Needle height



Teach



Straight line Shift Delete



Arc Zoom Save




Single point Advance Exit

Generated circle fill graph

Teach three points of the circle which needs to be filled, and it will automatically generate a spiral-like filled shape. When the diameter of the glue gun can not be divisible by the radius of the circle, there will be indicative messages that whether to enlarge or reduce the diameter of the glue gun to make it can be divisible by the radius of the circle.

- Fillet rectangle



生成圆角矩形

Generate fillet rectangle




Left vertex: Teach



Right vertex: Teach



Top vertex: Teach



Bottom vertex: Teach



Start point: left or bottom center point

轨迹方向: 顺时针

Track direction: CW

圆角半径: 3.0

Corner radius:

确定 取消

OK Cancel



上一页
下一页
指定点

Page up
Page down
Specify point

起 点
-直 线
-顺 圆 弧
-圆弧终点
-直 线

Start point
Straight line
CW arc
Arc end point
Straight line

滞后开胶: 否

Lag open jet: No

速度:

Speed

类型 定位 插入

Type Position Insert

针高

Needle height

教导

Teach

直线 平移 删除

Straight line Shift Delete

圆弧 缩放 保存

Arc Zoom Save

单点 高级 退出

Single point Advance Exit

Generated fillet rectangle graph

Press the "Teach" key in the fillet rectangle interface to teach each vertex of the rectangle. Select the starting point (starting point can only choose the midpoint of the long side), select the runway direction, and press OK to generate a fillet rectangle. The data of all vertexes in this interface are saved at all times, even you exit the interface. Therefore, you can exit midway while teaching the oval and the data will still be there when you re-enter.

4.1.9 Find type

Find the Nth same process point with the specified type, press the Shift +9 quick access to the file editing interface, and then press Shift + the up arrow or Shift + down arrow to find previous or next point of this type.

4.1.10 Adjust area

Adjust the coordinates of the graphics between the current point and the next reference point. The first point of the graph in the area will be adjusted to the current coordinates, and the other parts of the graphics will be adjusted as well. This feature is mainly used in the partial adjustment of area in the graphics array, the array of graphics need a reference point, the reference point is used to adjust the height of needle, and does not produce the actual movement. When you adjust, first use the feature of "Find Type" to find the reference point which needs to be adjusted, and then do partial adjustment.

4.1.11 Multiple arrays




多重阵列

Multiple arrays



Copy range:

Start point: End point:



Single array rows and columns: X prior



Array pitch



Double array rows and columns: X prior



Array pitch



Triple array rows and columns: X prior



Array pitch



OK Cancel

- Copy range: start processing point number and end processing point number of the graphics to be copied.
- Single array rows and columns: group number in X direction and Y direction of single array. The

copied object is the processing points specified in the copy range.

- Offset: the direction that the array starts copying.
- Array pitch: the pitch between the X and Y directions of single array copy.
- Double array rows and columns: group number in X direction and Y direction of single array. The copied object is the processing points after single array copy.
- Offset: the direction that the array starts copying.
- Array pitch: the pitch between the X and Y directions of double array copy.
- Triple array rows and columns: group number in X direction and Y direction of single array. The copied object is the processing points after double array copy.
- Offset: the direction that the array starts copying.
- Array pitch: the pitch between the X and Y directions of triple array copy.
- OK: generate multiple arrays according to set parameters.
- Cancel: exit multiple array function.


4.2 PLT graph importing function

Set the PLT file conversion proportion in system parameters, and then press “File manager” -> “PLT file conversion” in the main interface to select PLT files and convert into processing files of the same name with .DJJ suffix, save in “\PRG\” folder automatically, and then exit to the main interface for debugging and processing. PLT format is a format of printing file containing XY coordinate, starting point, end-point, and color of graph without info about Z-axis coordinate. Therefore, graph after conversion does not have Z-axis coordinate and needle height value. You can use the batch modification function to modify the Z-axis coordinate and needle height. There are many kinds of software generating PLT files. Here, we just introduce the ways of generating PLT files using two kinds of widely used software: CorelDRAW 12 and AutoCAD 2004. The interface may be a little bit different in case of different version.

4.2.1 Use CorelDRAW 12 to generate PLT files

<1>. Draw the graph

<2>. Click menu “File” → “Export”, and a dialog box appears as follows:




<3>. Select PLT-HPGL Plotter File in “Type”, and click “Export”, a dialog box appears as follows:





<4>. In “Page” tab, select “Bottom left” in “Graphic plotter origin”, and leave other settings as default.




<5>. In “Advance” tab, tick off “No width or speed order”, and leave others as default. Then, press OK to generate PLT file.

4.2.2 Use AutoCAD2004 to generate PLT files

Please check whether there is a printer named “Universal SHPGL” in printer type. If no, follow the following steps to install:


Click menu “File” → “Printer Manager” to pop up the interface as below



Double click the icon of “Add Printer Wizard”, and click “Next” to enter the following interface:




Continue to click “Next”




Select “Universal SHPGL” printer of HP, and keep clicking “Next” until the finish of printer installation. After the finish of installation, you can then export the PLT file in the following steps:

<1>. Draw the graph


<2>. Click “File” → “Print” to pop up the dialog box as below



<3>. Select “Universal SHPGL.PC3” printer in “Printer device”, check the “Print to file” check box, and set the path and name of the exported file



<4>. In “Print setup”, uncheck “Print style” and “Line width of printing object” in the printing options. Pay attention to the selection of “Graph direction”. A wrong selection may lead to wrong direction of the exported graph (Take letter “A” normal display as standards).




<5>. Click “OK” to export PLT file

PLT file can be opened by text editor. The following is a sample of PLT file:

```
_.(_I81;;17:_N;19:IN;SC;PU;IP;IW;VS20,1;VS20,2;VS20,3;VS20,4;VS20,5;VS20,6;VS20,7;VS20,8;SP1;
PU;PA0,0;SP1;LT;PA3985,3940;PD;PA5344,3940;PA5344,2497;PA3985,2497;PA3985,3940;PU;PA0,0;SP;P
G1;
```


4.2.3 Changing sequence of PLT file track with CorelDRAW12

<1>. The adjustment of point sequence inside the curve




As shown in picture above, we can see that one endpoint of the curve is big and the other one is small.


Big endpoint means the starting point, and the small endpoint means the end-point. To change their sequence, use the method below:



Left click on the icon on the second row of the left toolbar, select shape tool (as above picture), right click an endpoint of the curve, and select “Reverse curve”; then, the point sequence within the curve will be changed. (As the following picture)




The graph after reversing is as follows:





<2>. Graph sorting

If a graph is a group, you need to cancel the grouping of the graph. To do this, right click on the graph, and select “Cancel all grouping” (As the picture below):




Generate several curves (As picture below):

(To open the object manager on the right side, click “Tool”→“Object manager”)




Select any one of the curves (As picture above), you can name it, and move it to the desired position (as picture below):




Export PLT file when the sequence is arranged. Remember the position of starting point, which is the position when setting the starting point position during the processing.

4.2.4 Importing dxf files with CorelDRAW12

After generating dxf file with AutoCAD, you have to close AutoCAD before importing dxf file into CorelDRAW; otherwise, the import will fail. Pay attention to the unit when using AutoCAD. If you use millimeter, the zoom unit should use “Metric system”; if you use inch, select the “Imperial system”.



You'd better put the imported graph on the bottom left corner of the page (as picture below)



4.3 G code importing function

In main interface, you can press “File manager” -> “G code conversion” to switch the G code files to processing files with .DJJ suffix.

The supported G codes nowadays include G00, G01, G02, G03, G17, G18, G19, G90, G91, G20, G21, and too change instruction begun with T.

4.4 TCF file conversion function

In the main interface, press the "File manager" -> "TCF file conversion" to select TCF file, open and convert into processing files of the same name with .DJJ suffix, which is automatically stored in "\ PRG \" folder, and then exit to the main interface for debugging and processing. TCF file may be obtained by drawing with Logoshop drop processing software. TCF file saves the XY coordinates, reference point, starting point, end point, selected glue gun and other information of the graph, but the Z-axis coordinate information isn't saved, so that the converted graph doesn't have Z-axis coordinates and pin height value, which can be modified in batch edit.

4.5 USB connection and USB disk usage

USB connection: First, connect the controller and the PC using the USB cable, then press the "File manager" -> "USB connection" in the main interface, and the controller will be connected to the PC as USB disk.

USB disk usage: first connect the USB disk to the USB interface (only store useful files in the disk, because too many files will extend the reading time). In the main interface, press the "File manager" -> "File operation" to enter into the file management interface, press "Up" to find the "Removable Disk" (reading U disk requires a period of time), select and open USB disk. You can copy, paste, or delete files in the USB disk or controller.

Note:

1. After PLT files is generated, in the transferred files with the suffix of DJJ, there are empty command in both the beginning and end, it is recommended to manually remove them, so as not to affect the process.
2. Be sure to back up before Smoothing Graphics, just one opportunity to chamfer for each file.
3. External quick file selection and processing switch are invalid while the file is being edited.
4. Quick layer selection or quick file selection function are set as follows: 1. In the main interface, enter "System settings" -> "Factory parameters", select the "input port configuration", select the layer or the input point corresponding to the shortcut file number; 2. In the main interface, enter the "File Preferences" interface, select the layer for the glue gun or the number corresponding to the file.
5. After converting TCF file, you should not start to process until you perform the needle calibration or graph shift.
6. Gun-related parameters such as delay, advance, arrive and retreat are not valid unless the gun signal of the cylinder is effective.
7. Manual tuning method as follows: press axis movement button once. Each time you press the movement button and the corresponding axis will move the distance which is set for one fine-tuning pulse.
8. Reference for cycle processing steps: 1. In the main interface, press "System settings" -> "User parameters" to open circulation; 2. Set the number and times of cycle files, which correspond to the selected file under the "quick file number selection" of "File Preferences"; 3. Select a processing file for cycle, and then start cycle; if there is outer cycle selection switch, the cycle open and close of the hand-held box is invalid.
9. Please note that the quick selection file, the corresponding number of the file, and the corresponding layer of the file are three different conceptions.